

**TABLA DE CONVERSIÓN DE DIFERENTES MÉTODOS DE
DETERMINACIÓN DE VISCOSIDAD**

Viscosity Measurement Method	VISCOSITY IN CENTIPOISE											
	10	20	50	100	200	500	1,000	2,000	5,000	10,000	20,000	50,000
ASTM.07				72	143	357	715	1,430	3,750	7,150	14,300	35,700
ASTM.10					42	104	208	417	1,041	2,080	4,170	10,410
ASTM.15						24	48	95	238	476	953	2,380
ASTM.20						8	16	33	82	164	328	820
ASTM.25							7	14	36	72	143	357
Brookfield	10	20	50	100	200	500	1,000	2,000	5,000	10,000	20,000	50,000
Demmier #1				32	63	156	312					
Demmier #10				3	6	15	31					
Engler (Degrees)				14	27	68	137	274	685	1,370	2,740	6,850
Engler (Sec.)				690	1,300	3,460	7,000	14,000	34,800	70,500		
Ford #3				42	84	208	416	834	2,081	4,160	8,340	20,810
Ford #4				30	55	135	270	540	1,350	2,700	5,400	13,500
Fisher #1	20	30										
Fisher #2		15	24	50								
Gardner-Holdt (Units)	A-3	A-2	A	D	H	S	W	Y-Z	Z3	Z5	Z6-Z7	Z7-Z8
Gardner-Holdt (Sec)						5	10	20	50	100	200	500
Gardner-Vertical (Sec)						5	10	20	50	100	200	500
Krebs-Stormer (Units)	85	105	140			67	85	105	140			
Saybolt Furol			24	48	96	238	476	954	2,380	4,760	9,540	23,800
Saybolt Universal		96	238	476	954	2,380	4,760	9,540	23,800	47,600	95,400	
Zahn G1		38	60	100	267	667	1,332	2,670	6,670	13,320	26,700	66,700
Zahn G2		16	24	42	82	161	323	645	1,610	3,230	6,450	16,100
Zahn G3					27	58	113	204	510	1,020	2,040	5,100
Zahn G4					19	38	71	160	400	800	1,600	4,000
Zahn G5					13	27	50	97	212	424	848	2,120